



THE AIRPLANE FACTORY (Pty) Ltd, Registration no 2002/022837/07
Hangar 8 Tedderfield Airpark, Nettleton Road, Eikenhof, 1872, Johannesburg South
PO Box 308, Eikenhof, 1872, South Africa. Tel: +27 (0) 11 948 9898 Fax: +27 (0) 86 632 4493
E-mail: sales@airplanefactory.co.za Web: www.airplanefactory.co.za

SAFETY ALERT

#0003

Page 1 of 2

The Airplane Factory (Pty) Ltd considers compliance with all Safety Alerts mandatory

RELEASE DATE: 29-11-2013

EFFECTIVE DATE: January 2013

SUBJECT: Unable to set flap position with the 4-position flap controller.

MODELS AFFECTED: Flap actuators P/N: DLA-12-20-A-100-POT-1P65 purchase between January 2013 and November 2013 from The Airplane Factory (Pty) Ltd

COMPLIANCE TIME: Before first test flight of aircraft

PURPOSE: Three capacitors need to be removed for the flap actuator to work with the 4-position flap controller. "e-Flaps" P/N 2071 or Inotech flap controller.

PARTS/EQUIPMENT LIST: No.2 Philips screwdriver, pair of small side cutters.

INSTRUCTIONS: Remove motor casing from flap actuator carefully, cut the legs of the three capacitors and replace casing. You will now be able to set your flaps to the specific degrees.

